




RC 8 Weatherproof Loudspeaker




When choosing loudspeaker mounting location, please be aware of cabinet dimensions and leave enough clearance for angling.



Connect speaker line to loudspeaker input terminals and rotate dial to choose correct voltage and required power level.



Take extra care when opening and putting back loudspeaker cable cover - it contains seals for dust and moisture protection.



Fix the loudspeaker to the wall. Set required angle and tightened screws on the bracket.

Please pay attention: Mount loudspeaker on the reliable base only.